



CABINETY, INC.

## Cup Hinge Adjustment

### • Cup Hinges – Grass Tec #864


The Grass Tec hinges offer Zero Protrusion, which keeps them from interfering with all types of pull out units, yet they still allow for *vertical*, *horizontal* and *in/out adjustments*. The in/out adjustment can be used to remove the “*warped door*” look that up until now has required a replacement door. We strongly encourage this adjustment be used before ordering replacement doors due to warping. Below are a couple of pictures that should help you in understanding the *adjustability* of these hinges.

#### Hinge Adjustments


**1** Side Adjustment ..... +/-1.5mm  
Rotate screw clockwise or counterclockwise.

**2** Height Adjustment..... +/-2mm  
Loosen screw 2, align door, tighten screw 2.

**3** Depth Adjustment.....+2.5/- .5mm  
achievable through cam adjustment



1/2" Overlay




Full Overlay

The Grass cup hinges are still self closing, they fit into the hole pattern of our previous cup hinges and also carry our lifetime warranty.

To adjust a warped door, follow these steps:

#2 Then use the “depth adjustment” on the hinge in this corner. You will need to move the door away from the cabinet frame at this hinge.



#1 If the door appears to be warped and is away from the cabinet frame in this corner.